


Quick Start Guide



CLEARCUBE

Applying R1350 Label to R1350 LCD Panel



Apply the R1350 label to the front LCD panel of an R1350 blade to help distinguish the blade from an R1300 blade.

Applying R1350 Label

1. Remove the release liner (paper backing) from the label.
2. Press the label firmly onto the top edge of the LCD panel, ensuring that the label is centered.

See *R Series Product Manual* for more information about the R1350 blade.



Email support@clearcube.com
Web site support.clearcube.com
Toll-free (866) 652-3400
Phone (512) 652-3400

WEEE Initiative Notice

This electronic product is recyclable under WEEE (Waste Electrical and Electronic Equipment) guidelines and should not be discarded as regular trash.

Locate your nearest recycling facility to ensure proper disposal of this product.

For more information, see <http://support.clearcube.com/> or email recycle@clearcube.com.



G0200106 Rev A