

Topic: R2200 BIOS Update Version 2.00
Component(s) Affected: R2200 Blade
Date: October 23, 2006

OVERVIEW / ENVIRONMENT

An updated BIOS for the R2200 blade corrects an issue that causes blades to occasionally disappear in Switch Manager and Sentral.

DETAILED DESCRIPTION

The BIOS for the R2200 blade has been updated to version 2.00. This version corrects an issue that causes R2200 blades to occasionally disappear in Switch Manager and Sentral.

Note: Installing previous BIOS versions is not recommended.

RESOLUTION

To update your R2200 BIOS to version 2.00, you need the following:

- USB floppy drive
- Bootable DOS floppy disk
- The update BIOS file `DX200U5.WPH`
- The `phlash16.exe` flash utility

To update your BIOS, do the following:

1. Download the `DX200U5.zip` file from the ClearCube Support website. This file contains the BIOS update, the `phlash16.exe` flash utility, and this Technical Bulletin.
2. Unzip this file and copy the `phlash16.exe` and `DX200U5.WPH` files to a bootable floppy disk.
3. Plug the USB floppy drive into the USB port on the front of your R2200 blade, and insert the bootable floppy disk.
4. Restart your system on the floppy drive and enter the following command:

```
phlash16 DX200U5.WPH
```
5. After upgrading to the `DX200U5.WPH` BIOS, shut down and restart the blade when the upgrade has completed. Disregard the `phlash16` on-screen message `press any key to restart...`

For more information, please contact ClearCube technical support.

support@clearcube.com
support.clearcube.com
(866) 652-3400
+1 (512) 652-3400

Email address for ClearCube Technical Support
ClearCube Support Website
Direct line in the US
Direct line from outside the US